

INSTALLATION INSTRUCTIONS: MCD MODBUS MODULE

Order Code: 175G9000

1. Introduction

Danfoss soft starters can be controlled and monitored across an RS485 serial communication network using the Modbus RTU and AP ASCII protocols.


For users requiring simple control of MCD 200 and MCD 500 soft starters using Modbus RTU or AP ASCII, the instructions below describe the installation and operation of the Modbus Module.

MCD 3000 soft starters have AP ASCII protocol support built in - see the MCD 3000 Users Manual for details of message formats. The MCD 3000 supports Modbus RTU control when used in conjunction with a Remote Operator.

This document describes Modbus and AP ASCII messaging and *Appendix A* describes how to connect the Remote Operator and use it as a Modbus RTU or AP ASCII slave device.


2. Installation

1. Remove control power and mains supply from the soft starter.
2. Attach the Modbus Module to the starter as shown.
3. Apply control power to the soft starter.



Remove the Modbus Module using the following procedure:

1. Disconnect the RS485 cable from the module.
2. Remove control power and mains supply from the soft starter.
3. Push a small flat-bladed screwdriver into the slots at the top and bottom of the module and depress the retaining clips.
4. Pull the module away from the soft starter.




CAUTION

Remove mains and control voltage from the soft starter before attaching or removing accessories. Failure to do so may damage the equipment.

3. Adjustment

Network communication parameters must be set on the Modbus Module. DIP switch settings take effect on the power-up of the Modbus Module via the soft starter.




4. Connection

For the Modbus Module to accept serial commands, a link must be fitted across terminals A1-N2 on MCD 200 Series starters.

In order for the MCD 500 to accept commands from the serial network, the soft starter must be in Auto On mode and links must be fitted to terminals 17 and 25 to 18.

In Hand On mode, the starter will not accept commands from the serial network but the starter's status can still be monitored.




N.B.!

If MCD 500 parameter 3-2 *Comms in Remote* is set to Disable Comms in Remote, the starter will not accept start or stop commands from the serial network (the starter will still accept reset commands and allow status monitoring).

5. Network Status LED

The Network Status LED indicates the state of the communications link between the module and the network.

LED operation is as follows:



| Off | On | Flashing |
|--|----------------------|------------------------|
| No connection or soft starter not powered up | Communication active | Communication inactive |



N.B.!:

If communication is inactive, the soft starter may trip if the Communications Timeout function has been set on the module. When communication is restored, the soft starter will require a Reset.

6. Modbus Register

| Register Address | Type | Description | MCD 201 | MCD 202 | MCD 500 | MCD 3000 | |
|--|--------------------------------|---|---|---------|---------|----------|---|
| 40002 Command | Single Write | 1 = Start | ■ | ■ | ■ | ■ | |
| | | 2 = Stop | ■ | ■ | ■ | ■ | |
| | | 3 = Reset | ■ | ■ | ■ | ■ | |
| | | 4 = Quick stop (coast to stop) | ■ | ■ | ■ | ■ | |
| | | 5 = Forced communication trip | ■ | ■ | ■ | ■ | |
| 40003 Starter status | Multiple Read | Bit | Description | | | | |
| | | 0 to 3 | 1 = Ready | ■ | ■ | ■ | ■ |
| | | | 2 = Starting | ■ | ■ | ■ | ■ |
| | | | 3 = Running | ■ | ■ | ■ | ■ |
| | | | 4 = Stopping (including braking) | ■ | ■ | ■ | ■ |
| | | | 5 = Restart delay (including Temperature check) | | | ■ | ■ |
| | | | 6 = Tripped | ■ | ■ | ■ | ■ |
| | | | 7 = Program mode | | | ■ | ■ |
| | | | 8 = Jog forward | | | ■ | |
| | | | 9 = Jog reverse | | | ■ | |
| | | 4 | 1 = Positive phase sequence (only valid if bit 6 = 1). Always = 0 | | | | |
| | | 5 | 1 = Current exceeds FLC | | ■ | ■ | |
| | | 6 | 0 = Uninitialised 1 = Initialised | | ■ | ■ | ■ |
| 7 | Always = 0 | | | | | | |
| 40004 Trip Code | Multiple Read | See Trip Code table. | | | | | |
| 40005 ¹ Motor current | Multiple Read | Average 3 phase motor current (A) | | ■ | ■ | ■ | |
| 40006 Motor temperature | Multiple Read | Motor temperature (thermal model) | | ■ | ■ | ■ | |
| 40007 Product Type and Version | Multiple Read | Bit | Description | | | | |
| | | 0 to 2 | Product parameter list version | ■ | ■ | ■ | ■ |
| | | 3 to 7 | 1= MCD 3000 4= MCD 200 7 = MCD 500 | ■ | ■ | ■ | ■ |
| 40008 Serial Protocol Version | Multiple Read | | ■ | ■ | ■ | ■ | |
| 40009 ² ~ Parameter management | Single Write and Multiple Read | Parameter 1-A (Motor FLC) to: <ul style="list-style-type: none"> MCD 500 Par. 20-6 (Pedestal Detect) MCD 3000 Par. 60 (Min Run Frequency) | | | ■ | ■ | |

¹ For MCD 500 models MCD5-0068B and smaller this value will be 10 times greater than the value displayed on the LCP.

² See the relevant soft starter literature for a complete parameter list. The first product parameter is always allocated to register 40009. The last product parameter is allocated to register 40XXX, where XXX = 008 plus total number of available parameters in the product.

**N.B.!:**

The numbering of parameter options via serial communications differs slightly from the numbering displayed on the LCP. Numbering via the Modbus Module starts at 0, so for Par. 2-1 Phase Sequence, the options are 1~3 on the LCP but 0~2 via the module.

7. Trip Codes

| Trip Code | Trip Name | MCD 201 | MCD 202 | MCD 500 | MCD 3000 |
|-----------|--|---------|---------|---------|----------|
| 1 | Excess start time | | ■ | ■ | ■ |
| 2 | Motor overload (thermal model) | | ■ | ■ | ■ |
| 3 | Motor thermistor | | ■ | ■ | ■ |
| 4 | Current imbalance | | ■ | ■ | ■ |
| 5 | Frequency (Mains supply) | ■ | ■ | ■ | ■ |
| 6 | Phase sequence | | ■ | ■ | ■ |
| 7 | Instantaneous overcurrent | | | ■ | ■ |
| 8 | Power loss (Power circuit) | ■ | ■ | ■ | ■ |
| 9 | Undercurrent | | | ■ | ■ |
| 10 | Heatsink overtemperature | | | ■ | ■ |
| 11 | Motor connection | | | ■ | ■ |
| 12 | Input A trip (Auxiliary input A) | | | ■ | |
| 13 | FLC too high (FLC out of range) | | | ■ | ■ |
| 14 | Unsupported option (Not available in 6-wire) | | | ■ | |
| 15 | Starter communication | ■ | ■ | ■ | ■ |
| 16 | Network communication | ■ | ■ | ■ | ■ |
| 17 | Internal fault | | | ■ | |
| 23 | EEPROM fail | | | ■ | |
| 26 | L1 phase loss | | | ■ | |
| 27 | L2 phase loss | | | ■ | |
| 28 | L3 phase loss | | | ■ | |
| 29 | L1-T1 Shorted | | | ■ | |
| 30 | L2-T2 Shorted | | | ■ | |
| 31 | L3-T3 Shorted | | | ■ | |
| 33 | Time-overcurrent (Bypass overload) | | ■ | ■ | |
| 35 | Battery/clock | | | ■ | |
| 36 | Thermistor circuit | | | ■ | |
| 255 | No trip | ■ | ■ | ■ | ■ |

8. Modbus Functions

The Modbus Module supports the following Modbus functions:

- 03 Read multiple registers
- 06 Write single register

Modbus broadcast functions are not supported.

MCD 200 soft starters (including Remote Operator):

- Read multiple registers 40003 to 40008
- Write single register 40002

MCD 500 soft starters:

- Read multiple registers starting from 40003 up to a maximum of 125 register blocks
- Write single register 40002 or 40009 to 40599



N.B.!

A multiple read across register boundary 40008/40009 will result in a Modbus Error code 05 at the Master.

Modbus Module version 3 and earlier (serial number xxxxxx-3) can read a maximum of 119 register blocks.

8.1. Master Configuration

For standard Modbus 11-bit transmission, the Master must be configured for 2 stop bits with No Parity and 1 stop bit for odd or even parity.

For 10-bit transmission, the Master must be configured for 1 stop bit.

In all cases, the Master baud rate and slave address must match those set on the Modbus Module DIP switches.

Command: Start

| Message | Starter Address | Function Code | Register Address | Data | CRC |
|---------|-----------------|---------------|------------------|------|------------|
| In | 20 | 06 | 40002 | 1 | CRC1, CRC2 |
| Out | 20 | 06 | 40002 | 1 | CRC1, CRC2 |

Starter status: Running

| Message | Starter Address | Function Code | Register Address | Data | CRC |
|---------|-----------------|---------------|------------------|------|------------|
| In | 20 | 03 | 40003 | 1 | CRC1, CRC2 |
| Out | 20 | 03 | 2 (bytes) | 3 | CRC1, CRC2 |

Trip code: Motor overload

| Message | Starter Address | Function Code | Register Address | Data | CRC |
|---------|-----------------|---------------|------------------|------|------------|
| In | 20 | 03 | 40004 | 1 | CRC1, CRC2 |
| Out | 20 | 03 | 2 (bytes) | 2 | CRC1, CRC2 |

Download parameter from starter

MCD 500: Read Parameter 1, Motor FLC (Parameter 1-1), 100 A

| Message | Starter Address | Function Code | Register Address | Data | CRC |
|---------|-----------------|---------------|------------------|------|------------|
| In | 20 | 03 | 40009 | 1 | CRC1, CRC2 |
| Out | 20 | 03 | 2 (bytes) | 100 | CRC1, CRC2 |

Upload parameter to starter

MCD 500: Write Parameter 4, Current Limit (Parameter 1-4), set = 400% FLC

| Message | Starter Address | Function Code | Register Address | Data | CRC |
|---------|-----------------|---------------|------------------|------|------------|
| In | 20 | 06 | 40012 | 400 | CRC1, CRC2 |
| Out | 20 | 06 | 40012 | 400 | CRC1, CRC2 |

9. Modbus Error Codes

| Code | Description | Example |
|------|---------------------------|--|
| 01 | Illegal function code | Function other than 03 or 06 |
| 02 | Illegal data address | Register number invalid |
| 03 | Not readable data | Register not allowed for data reading |
| 04 | Not writable data | Register not allowed for data writing |
| 05 | Data boundary fault | Multiple data transfer across data boundary or data size more than 125 |
| 06 | Invalid command code | e.g. writing "6" into 40003 |
| 07 | Illegal parameter read | Invalid parameter number |
| 08 | Illegal parameter write | Invalid parameter number, read only, or hidden parameter |
| 09 | Unsupported command | Sending a serial command to MCD 500 with parameter 3-2 = Disable control in RMT. |
| 10 | Local communication error | Communication error between Modbus slave and starter |



N.B.!:

Some of the above codes are different from those defined in the Modbus Application Protocol Specification available on www.modbus.org.

10. AP ASCII Protocol

The message fragments used to communicate with the Modbus Module as an AP ASCII slave device are shown below. The message fragments may be assembled into complete messages as described in the sections that follow.



N.B.!:

Data must be transmitted in 8-bit ASCII, no parity, one stop bit.

| Message Fragment Type | ASCII Character String or (Hexadecimal Character String) | | | |
|----------------------------|--|------------------|----------------|------------|
| Send address | EOT (04h) | [nn] [nn] | [lrc] [lrc] | ENQ or 05h |
| Send command | STX (02h) | [ccc] | [lrc] | ETX or 03h |
| Send request | | [ccc] | [lrc] | |
| Receive data | STX (02h) | [dddd] [dddd] | [lrc] [lrc] | ETX or 03h |
| Receive status | STX (02h) | [ssss] [ssss] | [lrc] [lrc] | ETX or 03h |
| ACK (acknowledge) | ACK (06h) | or | | |
| NAK (negative acknowledge) | NAK (15h) | or | | |
| ERR (error) | BEL (07h) | or | | |

nn = two byte ASCII number representing the soft starter address where each decimal digit is represented by n.

lrc = two byte longitudinal redundancy check in hexadecimal.

ccc = three byte ASCII command number where each character is represented by c.

dddd = four byte ASCII number representing the current or temperature data where each decimal digit is represented by d.

ssss = four byte ASCII number. The first two bytes are ASCII zero. The last two bytes represent the nibbles of a single byte of status data in hexadecimal.

10.1. Commands

Commands can be sent to the soft starter using the following format:



Possible error responses:




= Master = Slave (soft starter)

| Command | ASCII | Comment |
|---------------------------|-------|---|
| Start | B10 | Initiates a start |
| Stop | B12 | Initiates a stop |
| Reset | B14 | Resets a trip state |
| Quick stop | B16 | Initiates an immediate removal of voltage from the motor. Any soft stop settings are ignored. |
| Forced communication trip | B18 | Causes a communications trip |

10.2. Status Retrieval

Soft starter status can be retrieved using the following format:




177HA316.12

| Request | ASCII | Receive Status (ssss) | |
|----------------|-------|--------------------------|--|
| Trip code | C18 | See the trip code table. | |
| Starter status | C22 | Bit | Description |
| | | 0 to 3 | 1 = Ready 2 = Starting 3 = Running 4 = Stopping (including braking) 5 = Restart delay (including Temperature check) 6 = Tripped 7 = Program mode |
| | | 4 | 1 = Positive phase rotation (only valid if bit 6 = 1) |
| | | 5 | 1 = Current exceeds FLC |
| | | 6 | 0 = Uninitialised 1 = Initialised |
| | | 7 | 0 = Communications are OK 1 = Communications device fault |

10.3. Data Retrieval

Data can be retrieved from the soft starter using the following format:



177HA313.10

| Request | ASCII | Receive Data (dddd) |
|-------------------|-------|--|
| Motor current | D10 | Requests motor current. The data is four byte decimal ASCII. Minimum value 0000 A, maximum value 9999 A. |
| Motor temperature | D12 | Requests the calculated value of the motor thermal model as a % of motor thermal capacity. The data is four byte decimal ASCII. Minimum value is 0000%. Trip point is 0105%. |

10.4. Calculating the Checksum (LRC)

Each command string sent to and from the starter includes a checksum. The form used is the longitudinal redundancy check (LRC) in ASCII hex. This is an 8-bit binary number represented and transmitted as two ASCII hexadecimal characters.

To calculate LRC:

1. Sum all ASCII bytes
2. Mod 256
3. 2's complement
4. ASCII convert

For example Command String (Start):

| | | | | | | | |
|-------|-----|-----------|-----|-----|--------------------|--|--|
| ASCII | STX | B | 1 | 0 | | | |
| or | 02h | 42h | 31h | 30h | | | |
| ASCII | Hex | Binary | | | | | |
| STX | 02h | 0000 0010 | | | | | |
| B | 42h | 0100 0010 | | | | | |
| 1 | 31h | 0011 0001 | | | | | |
| 0 | 30h | 0011 0000 | | | | | |
| | A5h | 1010 0101 | | | SUM (1) | | |
| | A5h | 1010 0101 | | | MOD 256 (2) | | |
| | 5Ah | 0101 1010 | | | 1's COMPLEMENT | | |
| | 01h | 0000 0001 | | | + 1 = | | |
| | 5Bh | 0101 1011 | | | 2's COMPLEMENT (3) | | |
| ASCII | 5 | B | | | ASCII CONVERT (4) | | |
| or | 35h | 42h | | | LRC CHECKSUM | | |

The complete command string becomes:

| | | | | | | | |
|-------|-----|-----|-----|-----|-----|-----|-----|
| ASCII | STX | B | 1 | 0 | 5 | B | ETX |
| or | 02h | 42h | 31h | 30h | 35h | 42h | 03h |

To verify a received message containing an LRC:

1. Convert last two bytes of message from ASCII to binary
2. Left shift 2nd to last byte four bits
3. Add to last byte to get binary LRC
4. Remove last two bytes from message
5. Add remaining bytes of message
6. Add binary LRC
7. Round to one byte
8. The result should be zero

Response or status bytes are sent from the starter as an ASCII string:

| | | | | | | | |
|------|-------|--|-------|-------|------|------|-----|
| STX | [d1]h | [d2]h | [d3]h | [d4]h | LRC1 | LRC2 | ETX |
| d1 = | 30h | | | | | | |
| d2 = | 30h | | | | | | |
| d3 = | 30h | plus upper nibble of status byte right shifted by four binary places | | | | | |
| d4 = | 30h | plus lower nibble of status byte | | | | | |

For example status byte = 1Fh, response is:

| | | | | | | | |
|-----|-----|-----|-----|-----|------|------|-----|
| STX | 30h | 30h | 31h | 46h | LRC1 | LRC2 | ETX |
|-----|-----|-----|-----|-----|------|------|-----|

11. Appendix A - Modbus Control via Remote Operator


To control a soft starter via an RS485 serial communications network using the Remote Operator, connect the Remote Operator to the network as described in the following sections.

11.1. Grounding and Shielding

Twisted pair data cable with earth shield is recommended. The cable shield should be connected to a GND device terminal at both ends and one point of the site protective earth.

11.2. Termination Resistors

In long cable runs prone to excessive noise interference, termination resistors should be installed between the data lines at both ends of the RS485 cable. This resistance should match the cable impedance (typically 120 Ω). Do not use wire wound resistors.




11.3. RS485 Data Cable Connection

Daisy chain connection is recommended. This is achieved by parallel connections of the data cable at the actual device terminals.

11.4. Remote Operator RS485 Network Connection Specifications

- Input impedance: 12 kΩ
- Common mode voltage range: - 7 V to + 12 V
- Input sensitivity: ± 200 mV
- Minimum differential output voltage: 1.5 V (with max loading of 54 Ω)


11.5. Using the Remote Operator with MCD 200



11.6. Using the Remote Operator with MCD 500

In order for the MCD 500 to accept commands from the serial network, the soft starter must be in Auto On mode and links must be fitted to terminals 17 and 25 to 18.


The Modbus Module must be used as an interface between the soft starter and the Remote Operator. The DIP switches on the Modbus Module must be set as follows:



| | |
|---|----------------------|
| 1 | Protocol = AP ASCII |
| 2 | Address = 20 |
| 3 | Baud Rate = 9600 |
| 4 | Parity = No parity |
| 5 | Timeout = No timeout |

The Remote Operator internal parameters must be set as follows:


- Parameter 1 (RS485 network baud rate) = set to match Modbus master
- Parameter 2 (RS485 network address) = unique number between 1 ~ 99
- Parameter 3 (RS485 network timeout) = set as required
- Parameter 4 (RS485 network protocol) = Modbus RTU
- Parameter 5 (Modbus protocol parity) = set to match Modbus master



11.7. Using the Remote Operator with MCD 3000

In order to operate correctly on the network, the MCD 3000 must be set for local operation only (i.e. set Parameter 20 = 2). The Remote Operator's default communications protocol setting is AP ASCII. This must be changed to Modbus RTU.

The RS485 Network Timeout setting on the Remote Operator applies to the link between the Remote Operator and the network. This can be set to any value between 0 and 100 seconds.



The Serial Timeout setting on the MCD 3000 (Parameter 24) applies to communications between the Remote Operator and the MCD 3000. See the MCD 3000 Operating Instructions for soft starter configuration details.

11.8. Programming

The Remote Operator must be configured to operate on the network. In order to access Programming Mode, the Remote Operator must be powered up when the soft starter is not running.

11.8.1. Programming Procedure

1. To enter Programming Mode, hold down the Data/Prog pushbutton for four seconds. The default value of the first parameter will be displayed.
2. Use the Data/Prog pushbutton to advance to the next parameter.
3. Use the Stop/+ and Reset/- pushbuttons to adjust parameter values.

Programming Mode closes when the Data/Prog pushbutton is pressed after Parameter 8.



N.B.!:

There is a 20 second timeout when the Remote Operator is in Programming Mode. Programming Mode will automatically close if no input is registered for 20 seconds. Any changes already made will be saved.

11.8.2. Programmable Parameters

The Remote Operator offers the following programmable parameters:

| Parameter Number | Description | Default Setting | Adjustable Range |
|------------------|--|----------------------|--|
| 1 | RS485 network baud rate | 4 (9600 baud) | 2 = 2400 baud 3 = 4800 baud 4 = 9600 baud 5 = 19200 baud 6 = 38400 baud |
| 2 | RS485 network satellite address | 20 | 1 to 99 |
| 3 | RS485 network timeout | 0 seconds (= off) | 0 to 100 seconds |
| 4 | RS485 network protocol | 1 (AP ASCII) | 1 = AP ASCII protocol 2 = Modbus RTU protocol |
| 5 | Modbus protocol parity | 0 (no parity) | 0 = no parity 1 = odd parity 2 = even parity 3 = 10-bit transmission |
| 6 | Motor FLC (A) | 10 | 1 to 2868 |
| 7 | Analog output 4 mA offset (%) | 100 | 80 to 120 |
| 8 | Start, Stop, Quick stop function disable | 0 | 0 = Remote Operator and Network start, stop, quick stop function enabled. 1 = Remote Operator start, stop, quick stop function enabled. Network start, stop, quick stop function disabled. ** 2 = Remote Operator start, stop, quick stop function disabled. Network start, stop, quick stop function enabled. * 3 = Remote Operator start, stop, quick stop function disabled. Network start, stop, quick stop function disabled. *. ** |
| 9 | Current ÷ 10 | 0 | 0 = off (required for models MCD5-0084B ~ MCD5-1600C) 1 = on (required for models MCD5-0021B ~ MCD5-0068B) |

* Remote Operator Reset pushbutton is always enabled.

** RS485 Network reset and forced communication trip functions are always enabled.



N.B.!:

Remote Operator Par. 9 *Current ÷ 10* normalises the displayed current and analog output for models MCD5-0021B ~ MCD5-0068. Use Par. 9 in conjunction with Par. 6 *Motor FLC* as follows:

1. Set Par. 6 to a value 10 times greater than the actual motor nameplate FLC (e.g. for actual FLC = 4.6 A, set Par. 6 to 46).
2. Set Par. 9 = 1.

11.9. Troubleshooting

The Remote Operator display and status indication LEDs can indicate abnormal operating and system conditions.

| Display Indication | Problem | Possible Solution |
|-------------------------------|---|--|
| nEt on display | A loss of communication has been detected on the RS485 link to the network. | The Remote Operator has an RS485 Network Timeout Protection setting (Parameter 3). This error is reported when no communication occurs for longer than the timeout setting. The system will become active as soon as communication is restored. To clear nEt from the display, press the Data/Prog pushbutton momentarily or send a Reset command from the network Master. |
| SP flashing on display | Soft starter is off and being programmed from the serial network. | Finish soft starter network programming procedure and exit Programming Mode. |

12. Appendix B - Specifications

| Enclosure | |
|--|--|
| Dimensions | 35 mm (W) x 157 mm (H) x 90 mm (D) |
| Weight | 250 g |
| Protection | IP20 |
| Mounting | |
| Spring-action plastic mounting clips (x 2) | |
| Connections | |
| Soft starter | 6-way pin assembly |
| Network | 5-way male and unpluggable female connector (supplied) |
| Maximum cable size | 2.5 mm ² |
| Settings | |
| Protocol | Modbus RTU, AP ASCII |
| Address range | 0 to 31 |
| Data rate (bps) | 4800, 9600, 19200, 38400 |
| Parity | None, Odd, Even, 10-bit |
| Timeout | None (off), 10 s, 60 s, 100 s |
| Certification | |
| C✓ | IEC 60947-4-2 |
| CE | IEC 60947-4-2 |